


## IGNITION BLOCKING RELAY CONNECTION

### REQUIREMENTS:

- Simple automotive relay
  - 12 V 40 A for light vehicles
  - 24 V 40 A for trucks

Cut wire from ignition lock to starter motor and connect relay to ignition system according scheme.



### CONTACTS:

Main Support no.: +370 5 2045030  
Polish Support no.: +48 22 2092532  
Ukrainian Support no.: +380 947 107319

WEB: [www.ruptela.lt](http://www.ruptela.lt)

EMAIL: [support@ruptela.com](mailto:support@ruptela.com)